





38-39/6-004

| III No.              | Part No.  | DESCRIPTION                            | Qty. | Change Point | REMARKS                   |
|----------------------|-----------|----------------------------------------|------|--------------|---------------------------|
| CYLINDER SIDE COVERS |           |                                        |      |              |                           |
| 1                    | 12A 1212  | Cover—cylinder side—separator with oil | 1    |              | 1000, 1001 &<br>Minimatic |
| 2                    | 12A 1386  | Cover—cylinder side—plain              | 1    |              |                           |
| 3                    | 12A 1175  | Gasket—side cover                      | 2    |              |                           |
| 4                    | SH 605091 | Screw—side cover                       | 2    |              |                           |
| 5                    | 12A 1177  | Washer—cup                             | 2    |              |                           |
| 6                    | 12A 1176  | Bush (rubber)                          | 2    |              |                           |
| 7                    | 12A 1735  | Hose—oil separator to carburetter      | 1    |              |                           |
| 8                    | 3H 2963   | Clip                                   | 1    |              |                           |
| OIL SEPARATOR        |           |                                        |      |              |                           |
| 9                    | AXE 82    | Separator—oil                          | 1    |              | 1300                      |
| 10                   | AXE 84    | Plate—engine front                     | 1    |              |                           |
| 11                   | 12G 1114  | Gasket—oil separator                   | 2    |              |                           |
| 12                   | SF 604061 | Screw                                  | 1    |              |                           |
| 13                   | HZS 0405  | Screw                                  | 1    |              |                           |
| 14                   | LWZ 204   | Washer—spring                          | 1    |              |                           |
| 15                   | FNZ 504   | Nut                                    | 1    |              |                           |
| 16                   | AXE 265   | Hose—oil separator                     | 1    |              |                           |
| 17                   | 3H 2963   | Clip—hose                              | 1    |              |                           |
| 18                   | 12G 2512  | Adaptor—4-way                          | 1    |              |                           |
| 19                   | AXE 262   | Hose                                   | 2    |              |                           |
| 20                   | AXE 249   | Hose—oil separator                     | 1    |              |                           |
| 21                   | 3H 2963   | Clip—hose                              | 1    |              |                           |
| 22                   | 12G 2619  | Separator—oil                          | 1    |              |                           |
| 23                   | 12G 1114  | Gasket—oil separator                   | 1    |              |                           |
| 24                   | ZCS 0506  | Screw                                  | 2    |              |                           |
| 25                   | WL 600051 | Washer—spring                          | 2    |              |                           |